

**Toyota Nadia (1998-2003)**

SXN10	3S-FE	2WD	
SXN10	3S-FSE	2WD	
SXN15	3S-FE	4WD	
ACN10	1AZ-FSE	2WD	
ACN15	1AZ-FSE	4WD	

System	Capacity (l)	Type
<b>Lubrication (w filter)</b>		
		<p>The diagram shows a temperature scale from -30 to 40 degrees Celsius. Three oil grade indicators are shown as arrows pointing right: SAE 5W-20 covers the range from -30 to 40; SAE 5W-30 covers from -30 to 30; and SAE 10W-30 covers from -10 to 40.</p>
3S-FE	3.9	API SL
3S-FSE	4.0	API SL
1AZ-FSE	4.2	API SL
<b>Cooling</b>		
3S-FE	6.1	
3S-FSE	6.1	
1AZ-FSE	5.9	
<b>Automatic transmission</b>		
3S-FE	8.1	Toyota ATF D-II
3S-FSE	7.6	Toyota ATF Type T-IV
1AZ-FSE	8.2	Toyota ATF Type T-IV
<b>Transfer</b>		
	0.8	Toyota Hypoid Gear Oil SX API GL-5 SAE 85W-90
<b>Front differential</b>		
<b>Rear differential</b>		
	0.5	Toyota Hypoid Gear Oil SX API GL-5 SAE 85W-90
<b>Power steering</b>		
	0.8	Toyota Power Steering Fluid
<b>Washer tank</b>		
	2.5	
<b>Fuel tank (RON)</b>		
	60	"Regular" (91)